

INSTALLATION



1 Place the tile on the designated location and trace the perimeter with a thin permanent marker.

2 Set the tile aside and using a 4" diamond cup grinder, scour the concrete within the marked location and in correspondence with the location requiring adhesive as indicated in backside of tile.

3 Clear away the dust with a leaf blower then clean the back of the tile and the concrete with rag soaked in acetone.

4 Apply adhesive to back of tile (as indicated on tile). The first bead should be applied thin, 1/2" from the perimeter edge and a second thicker bead applied 1" inside of the first.

5 Set the tile true and square to the curb ramp and press down firmly.

6 While stepping down on either side of pre-formed hole, drill down 3" into concrete slab using a hammer drill and the recommended 1/4" diameter carbide drill bit.

7 While still applying pressure, remove the dust and any adhesive that surfaces and carefully set the supplied color-matched fastener with a hammer.

Repeat steps 6 & 7 while working across the tile from one end until all pre-formed fastener locations are completed.

8 Clean the perimeter of the tile and the immediately surrounding concrete with acetone making sure to remove any adhesive that has escaped from beneath the tile.

9 Mask the edge of the tile and the concrete leaving a 1/2" gap back from the tile's perimeter edge.

10 Apply the perimeter sealant.

11 Using a plastic applicator or spatula smooth out the sealant in a cove profile between the tile and adjacent concrete.

12 Carefully remove the masking tape immediately after tooling the perimeter sealant.

SECTION A-A

SEE DETAIL C

www.accesstile.com 888-679-4022