

Installation Instructions Advantage® Cast Iron TWSI Plates

Prior Installation

- Ensure Field Measurements
- Compliance with Project Drawings and Specifications
- AODA Guidelines and Requirements

The Kinesik Advantage

- Leading TWSI Solutions Provider
- Manufacturer of Lightweight and Durable Plates
- Largest Selection of Standard and Radii Sizes
- Easy to Install



1. Connect multiple plates with 3/8" x 1-3/4" bolts.
2. After initial concrete set prepare plate for installation.
3. Without removing any concrete, set plate into sidewalk per owner specifications.
4. Using a level ensure installation is in compliance with AODA.
5. Tap plate in a grid pattern with rubber mallet until concrete pushes through vents.
6. Create edge with a 3/8" tool around perimeter of plate.
7. Clean plate and ensure no debris on surface.